MX610 & XM3150

Machine Type 7016-630, -67x

Service Manual

- Start diagnostics
- Maintenance
- Safety and notices
- Trademarks
- Index

February 02, 2014 **www.lexmark.com**

P/N 12G2272

Product information

Product name:
Lexmark MX610 Series

Machine type:
7016

Model(s):
630, 670, 675

Edition notice

February 02, 2014

The following paragraph does not apply to any country where such provisions are inconsistent with local law: LEXMARK INTERNATIONAL, INC., PROVIDES THIS PUBLICATION “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

References in this publication to products, programs, or services do not imply that the manufacturer intends to make these available in all countries in which it operates. Any reference to a product, program, or service is not intended to state or imply that only that product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any existing intellectual property right may be used instead. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by the manufacturer, are the user’s responsibility.

Trademarks

Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

PCL® is a registered trademark of the Hewlett-Packard Company.

All other trademarks are the property of their respective owners.

© 2012 Lexmark International, Inc.

All rights reserved.

P/N 12G2272

Table of contents

Product information....2

Edition notice....2

Notices and safety information....15

Laser notices....15

Safety information....18

Preface....23

Service manual conventions....23

Change history....23

General information....27

Media guidelines....27

Paper guidelines....27

Using recycled paper and other office papers....29

Using specialty media....30

Supported paper sizes, types, and weights....32

Data security notice....34

Tools required for service....35

Diagnostic information....37

Troubleshooting overview....37

Performing the initial troubleshooting check....37

Power-on Reset (POR) sequence....38

Using Safe Mode....38

Fixing print quality issues....39

Initial print quality check....39

Gray background or toner fog check....40

Repeating defects check....41

Blank pages check....41

Solid black pages check....42

Shadow images check....42

Skewed print check....43

Streaked horizontal or vertical lines check....45

Toner smear check....46

Toner specks check....47

Paper jams....47

Avoiding jams....48
Understanding jam messages and locations....49
200 paper jams....50
202 paper jams....59
23y paper jams....62
241 paper jams....64
242–244 paper jams....68
25y paper jams....76
28y paper jams....79
29y paper jams....82
45y paper jams....83
Understanding the printer messages....99
Cartridge, imaging unit mismatch [41.xy]....99
Cartridge low [88.xy]....99
Cartridge nearly low [88.xy]....99
Cartridge very low, [x] estimated pages remain [88.xy]....99
Change [paper source] to [custom type name] load [orientation]....100
Change [paper source] to [custom string] load [orientation]....100
Change [paper source] to [paper size] load [orientation]....100
Change [paper source] to [paper type] [paper size] load [orientation]....100
Check tray [x] connection....100
Close front door....101
Close flatbed cover and load originals if restarting job [2yy.xx]....101
Complex page, some data may not have printed [39]....101
Configuration change, some held jobs were not restored [57]....101
Defective flash detected [51]....102
Disk full [62]....102
Disk must be formatted for use in this device....102
Disk near full. Securely clearing disk space....102
Error reading USB drive. Remove USB....102
Error reading USB hub. Remove hub....102
Fax memory full....102
Fax partition inoperative. Contact system administrator....102
Fax server 'To Format' not set up. Contact system administrator....103
Fax Station Name not set up. Contact system administrator....103
Fax Station Number not set up. Contact system administrator....103
Imaging unit low [84.xy]....103
Imaging unit nearly low [84.xy]....103
Imaging unit very low, [x] estimated pages remain [84.xy]....103
Incompatible tray [x] [59]....103
Incorrect paper size, open [paper source] [34]....104
Insufficient memory to collate job [37]....104
Insufficient memory for Flash Memory Defragment operation [37]....104
Insufficient memory, some Held Jobs were deleted [37]....104
Insufficient memory, some held jobs will not be restored [37]....104

Insufficient memory to support Resource Save feature [35] 104
Load [paper source] with [custom type name] [paper orientation] 105
Load [paper source] with [custom string] [paper orientation] 105
Load [paper source] with [paper size] [paper orientation] 105
Load [paper source] with [paper type] [paper size] [paper orientation] 105
Load Manual Feeder with [custom type name] [paper orientation] 106
Load Manual Feeder with [custom string] [paper orientation] 106
Load Manual Feeder with [paper size] [paper orientation] 106
Load Manual Feeder with [paper type] [paper size] [paper orientation] 106
Maintenance kit low [80.xy] 106
Maintenance kit nearly low [80.xy] 107
Maintenance kit very low, [x] estimated pages remain [80.xy] 107
Memory full [38] 107
Memory full, cannot print faxes 107
Memory full, cannot send faxes 107
Network [x] software error [54] 107
No analog phone line connected to modem, fax is disabled. 107
Non-Lexmark [supply type], see *User's Guide* [33.xy] 108
Not enough free space in flash memory for resources [52] 108
Paper changes needed 108
Parallel port [x] disabled [56] 108
Printer had to restart. Last job may be incomplete. 109
Remove defective disk [61] 109
Remove paper from standard output bin 109
Replace defective imaging unit [31.xy] 109
Replace cartridge, 0 estimated pages remain [88.xy] 109
Replace imaging unit, 0 estimated pages remain [84.xy] 109
Replace maintenance kit, 0 estimated pages remain [80.xy] 109
Replace all originals if restarting job. 109
Reinstall missing or unresponsive cartridge [31.xy] 110
Reinstall missing or unresponsive imaging unit [31.xy] 110
Replace unsupported cartridge [32.xy] 110
Replace unsupported imaging unit [32.xy] 110
Restore held jobs? 110
Scanner automatic feeder cover open 110
Scanner disabled by admin [840.01] 111
Scanner disabled. Contact system administrator if problem persists. [840.02] 111
Scanner jam, remove all originals from the scanner [2yy.xx] 111
Scanner jam, remove jammed originals from the scanner [2yy.xx] 111
Serial port [x] disabled [56] 111
SMTP server not set up. Contact system administrator. 111
Some held jobs were not restored 111
Standard network software error [54] 111
Standard USB port disabled [56] 112
Supply needed to complete job 112

Too many flash options installed [58] 112
Too many trays attached [58] 112
Unformatted flash detected [53] 112
Unsupported disk 112
Unsupported option in slot [x] [55] 113
USB port [x] disabled [56] 113
Weblink server not set up. Contact system administrator. 113
User attendance messages 113
User attendance messages (0-99.99) 113
Toner cartridge smart chip contact service check 114
Imaging unit smart chip contact service check 115
Toner smart chip compatibility service check 115
Imaging chip compatibility service check 116
Printer/cartridge mismatch service check 116
Flash full service check 117
Maintenance kit service check 117
Insufficient memory service check 117
Imaging unit low service check 118
Toner cartridge low service check 118
Printer hardware errors 119
111 errors 120
121 errors 121
126 errors 123
132 errors 124
133 errors 125
140 errors 125
146 errors 126
155 errors 127
171 errors 128
Steps before starting the 9yy service checks 129
900 errors 131
912 errors 136
94y errors 136
950–958 errors 137
959 errors 139
96y errors 140
97y errors 141
98y errors 141
99y errors 142
Base printer symptoms 142
Dead machine service check 143
Controller board service check 144
Control panel service check 145
Toner starvation service check 146

USB print service check....147
Front door not closed service check....148
Network service check....149
Bin full service check....151
ADF/Scanner hardware errors....152
8yy error messages....152
Scanner disabled error service check....153
ADF service check....154
Scanner configuration error service check....155
Scan/fax/copy symptoms....155
Black or blank page copy service check....156
CCD service check....157
Flatbed motor service check....157
Flatbed home position service check....158
ADF rattling noise service check....158
Flatbed legal scan service check....159
ADF streak service check....159
ADF feed errors service check....160
ADF duplex service check....161
Modem/fax card service check....162
Blank spaces on incoming fax service check....163
Stretched words on incoming fax service check....163
Fax reception service check....163
Fax transmission service check....165
Fax error log codes....167
Escalating a fax issue to second-level support....171
Input/output option hardware errors....172
321–344 errors....172
381 errors....176

Service menus....177

Understanding the printer control panel....177
Using the printer control panel....177
Understanding the colors of the indicator and Sleep button lights....177
Understanding the home screen....178
Using the touch-screen buttons....180
Menus list....181
Diagnostics menu....182
Entering the Diagnostics menu....182
Registration....182
Scanner calibration....183
Print Tests....184
Print Quality Pages....184

HARDWARE TESTS 184
DUPLEX TESTS 187
INPUT TRAY TESTS 189
OUTPUT BIN TESTS 190
FINISHER TESTS 191
BASE SENSOR TEST 191
DEVICE TESTS 192
PRINTER SETUP 193
EP SETUP 195
REPORTS 197
EVENT LOG 197
Scanner tests 198
Exit Diags 202
Configuration menu 203
Entering the Configuration menu 203
Reset ADF Maintenance Kit Counter 203
Maintenance Counter Value 203
Reset Maintenance Counter 203
Print Quality Pages 204
Reports 204
Panel Menus 204
PPDS Emulation 205
Download Emuls 205
Safe Mode 205
Factory Defaults 205
Energy Conserve 206
Fax low power support 206
Min copy memory 206
Num pad job assist 206
Format fax storage 207
ADF edge erase 207
Flatbed edge erase 207
Scanner manual registration 207
Disable scanner 209
Paper Prompts 209
Envelope Prompts 209
Action for Prompts 210
Jobs on Disk 210
Disk Encryption 211
Wipe All Settings 211
Font Density 211
Font Sharpening 211
Reduced Curl 211
Require Standby 212
A5 Loading 212

UI Automation 212
LES Applications 213
Key Repeat Initial Delay 213
Key Repeat Rate 213
Clear Supply Usage History 213
Clear Custom Status 214
USB Speed 214
Automatically Display Error Screens 214
USB PnP 214
Restore factory defaults 215
Entering Invalid engine mode 215
Entering Recovery mode 216
Accessing the Network SE menu 216
Service Engineer menu 216
Accessing the service engineer (SE) menu 216
Service engineer (SE) menu 216
Fax service engineer (SE) menu 217
Repair information 219
Removal precautions 219
Data security notice 219
Handling ESD-sensitive parts 220
Controller board/control panel replacement 220
Restoring the printer configuration after replacing the controller board 221
Updating the printer firmware 223
Using the flash drive 223
Using a network computer 224
eSF solutions backup 224
Ribbon cable connectors 225
Zero Insertion Force (ZIF) connectors 225
Horizontal top contact connector 226
Horizontal bottom contact connector 229
Vertical mount contact connector 232
Horizontal sliding contact connector 235
Low Insertion Force (LIF) connector 238
Printhead assembly adjustments 239
Removal procedures 242
Left side removals 242
Left cover removal 242
Main drive gearbox removal 244
MPF solenoid removal 246
MPF gearbox removal 248
Reverse solenoid removal 251

Cartridge gearbox removal 252
Duplex gear assembly removal 253
Right side removals 255
Right cover removal 255
Memory access door removal 258
Tray present sensor removal 258
Cooling fan removal 259
Controller board removal 260
Controller board shield removal 262
Toner cartridge smart chip contact removal 264
Modem removal 266
Front side removals 267
Left front mount removal 267
Right front mount removal 268
Transfer roll removal 270
Cartridge plunger removal 271
Name plate cover removal 273
Front bin cover removal 275
Control panel assembly removal 276
UICC removal 280
USB cable bracket removal 282
Speaker removal 282
Cave light lens removal 283
Interface card removal 284
Control panel cover removal 285
Display removal 286
Keypad assembly removal 288
MPF tray removal 289
MPF pick roller cover removal 291
MPF pick roller removal 291
Bail removal 292
Jam access cover removal 293
Front access cover removal 294
Front door sensor removal 296
Front input guide removal 296
Separator pad removal 298
Bottom side removals 301
Power supply removal 301
Power supply shield removal 301
Duplex removal 302
Duplex sensor and input sensor removal 303
Index sensor removal 306
Media present sensor removal 306
Toner density sensor removal 308

Trailing edge sensor removal....309
Media present sensor flag removal....310
ACM assembly removal....314
Pick/lift motor gearbox removal....316
Tray guide removal....317
Rear side removals....319
Dust cover removal....319
Rear exit door removal....320
Rear cover removal....321
Redrive assembly removal....321
Redrive shaft removal....323
Fuser removal....325
Stapler cable removal....326
Diverter spring removal....327
Diverter cover removal....328
Top side removals....329
Top cover removal....329
Bin full sensor/lens removal....330
Bin full sensor cable removal....332
Laser scanning unit (LSU) removal....333
ADF/scanner removals....335
ADF separator roll removal....335
Flatbed cushion removal....336
Scanner front cover removal....337
ADF input tray removal....338
ADF unit removal....338
Scanner assembly removal....341
ADF top cover assembly removal....343
ADF cable removal....344
USB cable removal....345
USB wireless cable removal....346
ADF hinge removal....347
Flatbed assembly removal....348
Control panel ribbon cable removal....348
Speaker cable removal....348
Restraint pad removal....350
550-sheet option tray removals....351
Pick roller removal....351
Separator roll assembly removal....352
ACM assembly removal....354
Staple finisher option removals....357
Staple finisher option removal....357
Stapler cartridge access door removal....358
Staple roll holder removal....359

Stapler right cover removal 360
Stapler left cover removal 361
Stapler rear door removal 362
Sensor (stapler access door) removal 363
Stapler carriage assembly removal 363
Stapler door close limit switch removal 365
Stapler paddle motor removal 369
Stapler rear cover removal 369
Sensor (stapler rear cover) removal 370
Trapped staple access door removal 372
Stapler service cover removal 373
Stapler controller card removal 373
Stapler left tamper motor removal 373
Stapler right tamper motor removal 374
Stapler rear cover close limit switch removal 375
Stapler cooling fan removal 377
Stapler power supply unit removal 377
Stapler interface cable removal 379
Stapler top cover removal 381
Sensor (stapler bin full receive) removal 384
Sensor (stapler bin full send) removal 386
Sensor (stapler pass through) removal 389
Tamper main assembly removal 391
Tamper sub-assembly removal 392
Tamper drive belt removal 394
Diverter gearbox removal 395
Stapler accumulator assembly removal 398
Sensor (stapler right tamper HP) removal 398
Sensor (stapler left tamper HP) removal 399
Sensor (stapler paddle HP) removal 400

Component locations 403

Exterior locations 403
Front view 403
Rear view 404
Connectors 405
Controller board 405
Power supply 413

Maintenance 415

Inspection guide 415
Scheduled maintenance 416
Maintenance kits 416
Resetting the maintenance counter 417

Lubrication specification....417
Cleaning the printer....417
Cleaning the printer....417
Cleaning the scanner glass....418

Parts catalog....420

Legend....420
Assembly 1: Covers....421
Assembly 2: Imaging....423
Assembly 3: Control panel....425
Assembly 4: Electronics 1....427
Assembly 5: Electronics 2....429
Assembly 6: Frame....432
Assembly 7: Option trays....435
Assembly 8: Staple finisher option....437
Assembly 9: Staple finisher (right)....439
Assembly 10: Staple finisher (top)....441
Assembly 11: Staple finisher (rear)....443
Assembly 12: Staple finisher exit assembly....445
Assembly 13: Staple finisher tamper assembly....447
Assembly 14: Staple finisher accumulator assembly....449
Assembly 15: Maintenance kits....451
Assembly 16: Power cords....453
Assembly 17: Miscellaneous....455

Appendix A: Printer specifications....457

Electrical specifications....457
Operating clearances....457
Acoustics....458
Operating environment....458
Scanner specifications....458
Fax specifications....459

Appendix B: Options and features....461

Available internal options....461
Media handling options....461

Appendix C: Theory of operation....463

POR sequence....463

Printer control....463

Paper path information....463

Input tray....463

Multipurpose feeder (MPF)....464

Simplex printing....464

Duplex printing....465

Media handling components....466

Main drive gearbox....466

Autocompensator mechanism (ACM)....466

Key components....467

Sensors....467

Other key components....468

Electrophotographic process (EP process)....470

ADF theory....473

ADF theory of operation....473

Appendix D: Acronyms....477

Acronyms....477

Index....479

Part number index....489

Part name index....495